



E120184

Item	Part Number	Description
1	-	Vertical adjustment wheel
2	-	Electrical connector

Front fog lamps are an optional fitment on low specification vehicles and a standard fitment on high specification vehicles.

Two front fog lamps are located in apertures in the front bumper. The front fog lamps are located in the front bumper. Each lamp is secured to three lugs in the bumper and retained with self tapping screws and fasteners. Each lamp has an adjustment wheel which provide for the vertical alignment of the beam. Access to the adjustment wheel requires removal of the lamp bezel.

The fog lamp uses a 55W halogen H11 bulb which is located in a holder. The holder is located in a hole in the rear of the fog lamp housing and is turned to lock in position.

The front fog lamps are controlled by the lighting control switch. When the ignition is in ignition mode 6 and the lighting control switch is in the side lamp or headlamp position, the lighting control fog lamp switch can be pushed to activate the front fog lamps.

If the switch is pushed a second time the front fog lamps are switched off. A front fog lamp warning indicator is illuminated in the instrument cluster when the front fog lamps are active.

If the fog lamps are active when the lighting control switch is moved to the off position or the ignition is switched off, the fog lamps are de-activated and will need to be reselected on (if required) when the side lamps or headlamps are next selected on.

#### Front Fog Lamps Functionality (NAS and Canadian Markets Only)

The front fog lamps are powered by an additional relay (relay 5) which is located in the EJB in the engine compartment.

The front fog lamps operate as described previously but with the following differences which cover local laws governing lamp usage.

If the low beam headlamps and the front fog lamps are on at the same time, when the high beam headlamps are switched on, the front fog lamps will be automatically switched off. When the high beam headlamps are switched off, the front fog lamps will be switched back on automatically.

- NOTE: The front fog lamps will also be switched off if the headlamp high beam flash function is operated.